



- INSTALLATION NOTES:**
1. SELECT A SUITABLE MOUNTING LOCATION. NORMAL IS TO FASTEN TO THE PUMP DISCHARGE PIPE WITH A HOSE CLAMP.
 2. CUT TUBES TO MINIMUM USABLE LENGTH
 3. DO NOT OVER-TIGHTEN PLASTIC FITTINGS
 4. USE 2 WRENCHES TO TIGHTEN TUBE FITTINGS
 5. COLORS AND SIZES VARY TO GUIDE RECONNECTION DURING PUMP SERVICE EVENTS